

Question: What size window is safest for a #10 package with an address carrier width of 8-1/2"

Answer: 4-1/4" wide

Formula: Envelope width – addressed insert width + 3-1/4" = minimum window width

Example: #10 env. 9.5" – 8.5" = 1" + 3-1/4" = 4-1/4"

